

PICALIGN™



POWERED BY: AEROTECH | SANTEC | SENKO

A New State-of-the-Art for
Multichannel Active Alignments

Active Alignment of Arrays


An industry-wide challenge

- **Problem:** Alignments of multichannel optical arrays have complex loss penalties and are sensitive to misalignment in all 6 degrees of freedom.
- **Current state-of-the-art:** Manual processes and alignment algorithms optimize a single channel or couple of channels in few degrees of freedom, causing slow, suboptimal alignments.



Active Alignment in CPO Testing and Packaging

Future state




Industry Collaboration

Est. December 2024

- **Senko, Santec and Aerotech** established a partnership to develop new technology for aligning high channel count devices, including **algorithms designed specifically for arrays**.
- **Faster alignment times** and **improved signal loss** are achieved through **tighter integration** between motion controller and optical instrumentation.

SENKO®
Advanced Components




Company Profiles



Precision Motion Control

- 55+ years in precision motion
- Stage mechanics, drive electronics and motion control software
- Privately held with 500+ employees globally



Fiber Optic Communication

- 35+ years and global leader in fiber-optic connectivity
- Detachable CPO connectors
- Small form-factor faceplate and transceiver connectors




Optical Test Instrumentation

- 45+ years in fiber optic test and measurement
- CPO/PIC characterization tools
- Tunable and high power light sources, OPMs, switches, attenuators



PICALIGN™

Photonics alignment architecture



SENKO®


Advanced Components




AEROTECH



Example load and search routine



Move to search position





Execute high-dynamic search routines




Collect power level data and send to motion controller in real-time

Search space characterization





Live plotted signal during scan



Normalized, average power level (4 DOF)

Custom Objective Function

Single Channel Signal Power vs. Time



Custom Objective Function vs. Time

Time

The **Custom Objective Function** enables the user to optimize alignment parameters for each process, including:


- Setting thresholds for **maximum loss** per channel or **maximum divergence** between channels
- **Weighting more critical channels** (such as PM fibers) to prioritize during optimization

Example Convergence Plot

Patents Pending


Search parameters:

- Time-limited search
- Objective function defined as average of all channels
- Maximum identified through extended brute force search




Preliminary Test Results

Patents Pending




Initial takeaways

- By monitoring 8 channels simultaneously, 5-DOF alignment positions within **< 0.1 dB are achieved in a few seconds**, with < 0.01 dB achieved for longer searches.
- Depending on application requirements, **alignment time can be optimized to meet signal level thresholds** to maintain yield.
- Alignments using a similar characterization approach but only monitoring a **single loopback** resulted in objective function scores that were up to **12% worse** than multichannel monitoring.



Normalized power level averaged across all 8 channels (4 DOF)


- **Pre-defined interfaces** between motion control and optical instrumentation reduce system design time
- Devices can be configured and **tested as integrated platform** to streamline setup
- **Customizable parameters** and configurations to fit wide variety of test and assembly processes



PICALIGN™

Adaptable, application-specific configurations and interfaces

Multi-DOF Positioners



Split DOF Positioners



Flexible Stage Mechanics




Flexible APIs + I/O

PICALIGN™

Example Python GUI

Channel Parameters		
Channel	Weight	Threshold
Ch 1	1.00	0.500
Ch 2	0.00	0.500
Ch 3	0.00	0.500
Ch 4	0.00	0.500
Ch 5	0.00	0.500
Ch 6	0.00	0.500
Ch 7	0.00	0.500
Ch 8	0.00	0.500



PICALIGN™


A new state-of-the-art for multichannel photonic alignment

- By utilizing simultaneous multichannel signal monitoring and customizable objective functions, this new, adaptable architecture **significantly enhances active alignment for photonic test and assembly processes:**



Alignment Speed

Throughput dramatically increased



Coupling Efficiency

Signal loss significantly improved



Integration Simplicity

Startup challenges reduced or eliminated

View live demos of PICAlign at Aerotech's booth (5207) at OFC 2026!

OFC

Mar. 17 - 19 in Los Angeles, CA

- Aerotech - #5207
- Santec - #1029
- SENKO - #1139 + #5536



中壢總公司 / Chungli Headquarter :

桃園市中壢區(中壢工業區)安東路5號

No.5 Andong Road, Chungli District, Taoyuan City 32063

TEL : 886-3-462-6569 / FAX : 886-3-462-5586

台中辦事處 / Taichung Office :

台中市南區忠明南路760號5樓A3

5F-A3, No.760, Zhongming S. Rd., South District, Taichung City 40255

TEL : 886-4-2261-0357 / FAX : 886-4-2261-0355

台南辦事處 / Tainan Office :

台南市東區林森路一段395號8樓之13

8F-13, No. 395 Sec.1, Linsen Rd, East District, Tainan City 70151

TEL : 886-6-208-6550 / FAX : 886-6-208-6282